

BLEEDING THE POWER TRIM AND TILT UNIT (ON OUTBOARD)

NOTE: _____

Install the power trim and tilt unit onto the outboard before bleeding.

Bleed:

- Air bubbles
(from the power trim and tilt unit)

Bleeding steps

- (1) Connect the battery leads to the battery.
- (2) Loosen the manual valve ① by turning it counterclockwise until it stops.

